

CELL SHADE INSTALLATION INSTRUCTIONS

TOOLS YOU WILL NEED

Measuring Tape
1/4" Magnetic Nut Driver
Cordless Drill
Screwdriver
Ladder/Step Stool

HARDWARE YOU WILL RECEIVE

Cell Shade




Installation Brackets
Mounting Screws
Cord Cleat
Cord Cleat Screws



BLIND INSTALLATION

Hold the installation bracket in place $\frac{3}{4}$ " behind edge of drywall



With mounting screw already in magnetic driver, attach bracket to sill


Use two screws for each bracket

Repeat for second bracket on opposite side

If cell shade width is over 47" use third bracket provided for center of shade

Making sure the cell shade is facing towards the interior of house, an indicator is the pull cord is accessible, place headrail up to brackets with the top of headrail angled towards the top clip of brackets. Insert the front of brackets into the slot of the headrail, and once in place, push the rest of the headrail up and back towards the back of bracket until it latches on to the bottom of the headrail. Check bottom latches of brackets to make sure they were secured.





CORD CLEAT INSTALLATION

Find desired location at side of window for cord cleat, and mark
With a screwdriver, attach the cord cleat to the wall



OPERATING YOUR NEW CELL SHADES

Each shade comes with 1 pull cord for operating.

Pull the cord away from window to raise the fabric shade from the down position, and to lock in place at any desired position.

To release from the “locked” position, pull cord towards center of window.



CARE & CLEANING YOUR CELL SHADES

With a dust or fabric attachment attached to a vacuum cleaner, on a weak strength setting Run over the fabric of the cell shade until debris is removed.

For dust trapped in between the cell shade, compressed air can be used to free the area of dirt.

Do not get wet, or use cleaners of any kind unless approved by the manufacturer.